



**MRM-GD-CT**

4.6 cu ft



**MRM-GD-CT**

5.7 cu ft

## Countertop Merchandiser Instruction Manual

This manual contains important information regarding your unit. Please read this manual thoroughly prior to equipment set-up, operation, and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty.

# MOTAK

## IMPORTANT SAFEGUARDS

Please pay close attention to the safety notices in this section. Disregarding these notices may lead to serious injury and/or damage to the unit.



**DANGER:** Risk of fire or explosion - Flammable refrigerant used.

**DANGER:** Risk of fire or explosion - Do not puncture refrigerant tubing.

- To be repaired only by trained service personnel.
- Consult the manual/owner's guide before attempting to service this product.
- All safety precautions must be followed.
- Follow handling instructions carefully in compliance with local government regulations.

## ATTENTION

- **DO NOT** overload outlet, to minimize shock and fire hazards
- **DESIGNATE** one outlet for your unit.
- **DO NOT** spray the unit with water
- **DO NOT** use extension cords.
- **DO NOT** put your hands under the unit when the unit is required to be moved.

## UNPLUG UNIT

- **DO NOT** plug or unplug the cord with wet hands, to minimize shock and fire hazards
- Before maintenance and cleaning, please unplug the unit.
- When the unit is not in use for a long period of time, please unplug the unit from the outlet.
- After unplugging the unit, wait at least 10 minutes before re-plugging it. Failure to do so could cause damage to the compressor.

## PROPER GROUNDING REQUIRED

- To minimize shock and fire hazards, make sure that the unit is properly grounded.

## PROHIBITED

- **DO NOT** attempt to remove or repair any component.
- Make sure that the unit is not resting on or against the electrical cord or plug.
- **DO NOT** hang on the doors.
- **DO NOT** store any flammable and explosive gas or liquids inside the unit.
- **DO NOT** attempt to alter or tamper with the electrical cord.
- **DO NOT** set the desired temperature out of the recommended temperature range:  
(Refrigerator: 32°F - 55°F) (Freezer: -15°F - 20°F)

## BEFORE INSTALLATION:

- If the unit has recently been transported please let unit stand still for a minimum of 24 hours before plugging it in.
- Make sure that the desired temperature is reached before loading the unit product.
- Make sure that there is proper ventilation around the unit in the area where it will operate.
- Make sure all accessories are installed (i.e. shelves, shelf clips, casters) before plugging the unit in.
- Please read through the manual in its entirety.



## INSTALLATION:

1. The refrigeration system will operate most efficiently when it is installed in an area that has cool, dry air.
2. Ensure that there's at least 6 inches of clearance on both sides and the back of the cabinet.
3. Unit should be placed away from heat and moisture generating equipment such as oven, stoves, etc.
4. Unit should avoid direct sunlight.
5. Unit should be installed on a flat sturdy surface that is strong enough to support the total weight of the unit and its contents.
6. Be sure that the unit is properly grounded to minimize shock or fire hazards. All units are equipped with a three-prong ground plug on the service cord to ensure your safety and protection.
7. All units are designed for indoor use only. Outdoor use may cause irreparable damage to the unit.

## REGULAR MAINTENANCE

- **WARNING:** Disconnect power cord before cleaning any parts of the unit.

### CLEANING THE CONDENSER COIL

- For efficient operation, it is important that the condenser surface be kept free of dust, dirt, and lint. It is highly recommended that the condenser coil be cleaned at least once a month.
- Clean with a commercial condenser coil cleaner and brush the condenser fins from top to bottom. After cleaning, straighten any bent fins with a fine comb.

### CLEANING THE FAN BLADES AND MOTOR

If necessary, clean the fan blades and motor with a soft cloth. If it is necessary to wash the fan blades, first cover the fan motor to prevent moisture damage.

### CLEANING THE INTERIOR OF UNIT

- When cleaning the cabinet interior, use a solvent of warm water and mild soap.
- Do not use steel wool, caustic soap, abrasive cleaners, or bleach that may damage the stainless steel surface.
- Wash door gaskets on a regular basis, preferably weekly. Remove door gasket from the frame of the door, soak in warm water and soap for thirty (30) minutes, dry with soft cloth, and replace.
- Check door gaskets for proper seal after they are replaced.
- Periodically remove the shelves and pilasters from the unit and clean them with mild soap and warm water. To remove the pilasters, first remove the shelves and shelf brackets. Then, lift the pilaster up and out.



## TROUBLE SHOOTING

- Before requesting any service on your unit, please check the following points. Please note that this guide serves only as a reference for solutions to common problems.

| PROBLEM                              | CORRECTIVE ACTION                                                                                                 |
|--------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| COMPRESSORS WILL NOT START           | Check that the power cord is plugged in                                                                           |
|                                      | Check for blown fuse                                                                                              |
|                                      | Move the unit away for direct sunlight or equipment that generates heat.                                          |
|                                      | Ensure that the unit is in a well ventilated area with a minimum clearance of 6".                                 |
|                                      | Check the condenser, and clean if necessary.                                                                      |
|                                      | Check if there is a blockage in the air duct.                                                                     |
|                                      | Check that the temperature controller is set correctly.                                                           |
|                                      | Check to see if refrigerant charge is low.                                                                        |
|                                      | Ensure that the door is completely closed.                                                                        |
| POOR PERFORMANCE                     | Turn off the light switch, then turn it on again.                                                                 |
|                                      | Ensure that the bulb is properly installed in the socket.                                                         |
|                                      | Check to see if the bulb needs to be replaced.                                                                    |
| NOISY UNIT                           | Ensure that the unit is installed on a flat sturdy surface.                                                       |
|                                      | Check that there is at least a 6" clearance from the wall.                                                        |
|                                      | Check for any loose parts or mounting.                                                                            |
|                                      | Ensure the tubing is free from any contact that would cause rattling.                                             |
| CONDENSATION ON CABINET AND/OR FLOOR | Reduce the humidity in the surrounding area.                                                                      |
|                                      | Ensure that the gasket on the door or head is creating a proper seal. Gasket may need to be repaired or replaced. |

## RETAIN THIS MANUAL FOR FUTURE REFERENCE

- Please read the entire manual carefully before installing and operating. If certain recommended procedures are not followed, warranty claims will be denied.

|                       |  |
|-----------------------|--|
| <b>MODEL#:</b>        |  |
| <b>SERIAL#:</b>       |  |
| <b>PURCHASE DATE:</b> |  |

Notice: We reserve the right to make changes in design and specifications without prior notice.