

Assembly Instructions for Knock-Down Bun Pan Racks

1. Choose a level area for assembly.
2. Lay out parts:
 - (4) 3/4" x 1" ~ I-Beam Spacers
 - (2) 1" x 1-1/2" ~ Angle Spacers
 - (8) Pieces of 1" Channel, 1" Long
 - (2) Pre-Assembled Rack Sides
 - (8) 3/8" x 2" ~ Hex Bolts
 - (4) 1/4" x 1/2" ~ Carriage Bolts & Nuts
3. Attach all bar and angle spacers to one pre-assembled rack side as shown (**Do Not Tighten Bolts**).
4. Attach remaining pre-assembled rack side and tighten all bolts.
5. Install casters last.

