


Replacement Parts Chart

Eco Pumps



d




e




f



g



h (includes i)




i



Server Eco Pumps™ are NSF listed.
Plus, clean-in-place certification means proper
cleaning can be done without disassembly.

Server Eco Pumps™ (Except BP-1 Thick 88220)

Cleaning Brush, 1 1/4" Dia.	82049
Cleaning Brush, 21" Long	82526
Food Equipment Lubricant, 1/4 oz	40179
b* Optional: Gauging Collars	
1/2 oz Portion Reduction Collar	88205
1/4 oz Portion Reduction Collar	88204
1/8 oz Portion Reduction Collar	88313
c Stop Collar (required for operation)	
	88409



Not all pump styles are pictured.

pump/model	a head assembly	d seal	e pinch valve	f cap/lid	g spring	h cylinder assembly	i stainless steel ball
88000 BP-1, 38 mm	88303	83005	88202	88016	88166	88496	06022
88010 BP-1, 110 mm				88041		88311	
88020 BP-1, Crock	88304	83005	88202	88056	88166	88312	06022
88150 BP-1/4, 1/8-Jar	88175	88162	88188	87248	88189	88087	88258
88180 BP-1/4, 28 mm	88175	88162	88188	88213 & 88276	88189	88085	
88190 BP-1/2, 28 mm	88232				88233	88089	88258

Server Eco Pump BP-1 Thick

Cleaning Brush, 1 1/4" Dia.	82049
Cleaning Brush, 21" Long x 1/2"	84257
Food Equipment Lubricant, 1/4 oz	40179
b* Optional: Gauging Collars for BP-1 Thick Pump (only)	
1/2 oz Portion Reduction Collar	88879
1/4 oz Portion Reduction Collar	88888
1/8 oz Portion Reduction Collar	88887
c Stop Collar (fixed, incorporated into head)	
	none



pump/model	a head assembly	d seal	e pinch valve	f cap/lid	g spring	h cylinder assembly	i stainless steel ball	j extension tube, 2 1/2"
88220 BP-1, Thick	89215	100345	88203	88016	88166	88496	06022	88315