

Grill Bricks, Screens & Polishing Pads

- Apply with cooking oil to protect the grill, cure and remove excess cooked-on foods
- 40710 Grill Brick is a fast, efficient and sanitary way to clean hot or cold grills
- Plastic wrapping on Grill Brick dissolves to eliminate mess
- 40713 Grill Screen and 40711 Grill Polishing Pad attach to the 40712 Grill Pad Holder for a complete grill maintenance system



40710



40711



40712
40713
40711

Scratch Brushes

- Compact profile for heavy scraping and cleaning in tight, narrow spaces; provides quick, aggressive removal of grease and deposits
- Available with wood handles for cleaning hot grills and ovens
- Available in nylon, stainless steel or carbon steel wire bristles for normal to tougher cleaning jobs



Standard(00)



Prod No	Description	Handle	Color	Pack
Grill Bricks, Screens & Polishing Pads				
40710	3.5" x 4" x 8" Grill Brick	—	00	12 ea
40711	4" x 5" x .25" Grill Polishing Pads, 10 ea/pack, 6 pks/case	—	00	6 pks
40712	Grill Pad Holder	Plastic	00	10 ea
40713	4" x 5.5" Grill Screen, 20 ea/pack, 10 pks/case	—	00	10 pks
Scratch Brushes				
45779	11" Brush & Scraper with Carbon Steel Bristles	Wood	00	12 ea
40671	11.5" Scratch Brush & Scraper with Carbon Steel Bristles	Plastic	00	12 ea
40670	11.5" Scratch Brush with Carbon Steel Bristles	Plastic	00	12 ea
40672	11.5" Scratch Brush & Scraper with Stainless Steel Bristles	Plastic	00	12 ea
40027	11.5" Scratch Brush with Nylon Bristles	Plastic	00	12 ea
45571	20" Brush & Scraper with Carbon Steel Bristles	Wood	00	12 ea

NOTE: Equipment must be turned off prior to using Scratch Brushes