


HWB-2-7Q
(shown with
two 7QT-PAN
and 7QT-LID-1)



HWB-2-7Q



HWB-2-11Q



HWB-3-4Q

ADAPTERS – SUPPORT BARS


HWB-2-7Q	Adapter to convert Warmer to hold two 7-Quart Inserts (Models HWBI & HWB-FUL series only)
HWB-3-4Q	Adapter to convert Warmer to hold three 4-Quart Inserts (Models HWBI & HWB-FUL series only)
HWB-2-11Q	Adapter to convert Warmer to hold two 11-Quart Inserts (Model HWB-43 series only)
HWB12BAR	12" Pan Support Bar for Built-In and Drop-In Heated Wells
HWB20BAR	20" Pan Support Bar for Built-In and Drop-In Heated Wells
HWBGM12BAR	12" Pan Support Bar for Drop-In Modular/Ganged Models
HWBGM20BAR	20" Pan Support Bar for Drop-In Modular/Ganged Models
CWB12BAR	12" Pan Support Bar for Refrigerated Drop-In Wells
CWB20BAR	20" Pan Support Bar for Refrigerated Drop-In Wells

False Bottom for Drop-In Refrigerated Wells (Perforated False Bottom accessory, choose your appropriate pan size)


CWB-1FB	For CWB-1 (1-Part Accessory)
CWB-2FB	For CWB-2 (1-Part Accessory)
CWB-3FB	For CWB-3 (2-Part Accessory)
CWB-4FB	For CWB-4 (2-Part Accessory)
CWB-5FB	For CWB-5 (3-Part Accessory)
CWB-6FB	For CWB-6 (3-Part Accessory)

Support Bars


Choose the appropriate kit for CWB, HWBI or HWB series




CWB-3FB



HWB-FUL-MNT
Choose the appropriate kit for
HWB-FUL, HWB-43 or HWB-4Q,
-7Q, -11Q series



**HWB-MNT-REC or
HWB-MNT-RND**



HWBI2MANIF



BALLVALVE1INCH

MOUNTING KITS – VALVES

Necessary at your Well installation:

HWB-FUL-MNT	Mounting Kit for Combustible Countertops for HWB-FUL series only
HWB-43-MNT	Mounting Kit for Combustible Countertops for HWB-43 series only
HWB-4Q-MNT	Mounting Kit for Combustible Countertops for HWB-4Q series only
HWB-7Q-MNT	Mounting Kit for Combustible Countertops for HWB-7Q series only
HWB-11Q-MNT	Mounting Kit for Combustible Countertops for HWB-11Q series only
HWB-MNT-REC	Kit allows mounting to thick Countertops – 8 Brackets (HWBI and Rectangular HWB Heated Wells only)
HWB-MNT-RND	Kit allows mounting to thick Countertops – 4 Brackets (Round Heated Wells only)

External Manifold includes Individual Ball Valve for each Well – (Not available for the slim models)

HWBI2MANIF	2-Pan Accessory
HWBI3MANIF	3-Pan Accessory
HWBI4MANIF	4-Pan Accessory
HWBI5MANIF	5-Pan Accessory
HWBI6MANIF	6-Pan Accessory

Necessary at your Well installation:

BALLVALVE3/4	High Temperature ¾" NPT Ball Valve for units with Individual Drain(s) and no Manifold
BALLVALVE1INCH	High Temperature 1" NPT Ball Valve for units with Manifold Drain (Ganged Heated Wells only)
GATEVALVE3/4IN	High Temperature ¾" NPT Gate Valve for units with Individual Drain(s) and no Manifold
GATEVALVE1INCH	High Temperature 1" NPT Gate Valve for units with Manifold Drain (Ganged Heated Wells only)
HWB-RDH	Heated Well Remote Handle for ¾" drains only (requires a Ball or Gate Valve)



GATEVALVE1INCH



HWB-RDH
Attaches to
¾" Ball or
Gate Valve