

CLEANING & DESCALING

DRC033 Descaling Instructions

Ice Making System

- 1 Turn knob to the off position
- 2 Remove all ice from the bin
- 3 Pour 4 oz. Scotsman "Clear 1" Scale Remover into the reservoir
- 4 Turn machine on and let run for 2 hours
- 5 Pour hot water into the bin to melt any ice that has formed. Ice will likely look frosty and white
- 6 Clean bin by mixing some cleaner with hot water and scrub remaining scale remover
- 7 Rinse bin with hot water
- 8 Turn knob clockwise to restart

Regular sanitizing of drain system is recommended



Scan QR Code for Cleaning Video



Part #19-0653 Clear One
Concentrated Scale Remover