

a Classic Display Case

Slant Front. Rear Door.
Includes 2 — 280-T Trays.

ITEM	DESCRIPTION
280	10Wx10Dx11H
280-T	Replacement Tray



b Classic Display Case

Slant Front. Includes 2 Drawers.

ITEM	DESCRIPTION
258	10¼Wx18½Dx14H



c Classic Display Case

Slant Front. Rear Door.
Includes 3 — 280-T Trays.

ITEM	DESCRIPTION
P257	10Wx15Dx13½H
280-T	Replacement Tray



d Tongs Kit

Includes Tongs, Chain, Hook & Tape.

ITEM	DESCRIPTION
267	Tongs Kit



e Elite Case

3 Tray Unit — 9½" W with Tray
Depths of 11½", 13", & 15½".

ITEM	DESCRIPTION
1505-3	12Wx17Dx14½H



f Stackable Display Case

Includes 13" x 18" Clear Tray.

ITEM	DESCRIPTION
920	18½Wx14Dx6H
921	18½Wx14Dx10H
325-13-12	Replacement Tray



920



921