



CAST IRON

Take our pre-seasoned cast iron pots, pans and casseroles out of the oven and onto the table. Larger sizes available on pg. 182.

Fry Pans and Casseroles

- CIPRT5336** 9 ½ oz. (280.9 mL)
5 ¾" L x 3 ⅝" W x 1 ½" H, 7" L with Handles
(13.7 x 9.2 x 4.1, 17.8 cm)
- CIPS61** 9 ½ oz. (280.9 mL)
5 ¾" Sq. x 7/8" H, 7 ⅞" L with Handles
(14.6 x 2.2, 18.1 cm)
- CIS41** 3 ½ oz. (103.5 mL)
3 7/8" Dia. x 1" H, 6 7/8" L with Handle
(9.8 x 2.5, 17.5 cm)
- CIS51** 8 ½ oz. (251.4 mL)
5" Dia. x 1 ½" H, 8 ¼" L with Handle
(12.7 x 3.8, 21 cm)
- CIS61** 15 ½ oz. (458.4 mL)
6 ¼" Dia. x 1 ¼" H, 10" L with Handle
(15.9 x 3.2, 25.4 cm)

Round Casseroles and Pots

- CIPR5125** 8 ½ oz. (251.4 mL)
5" Dia. x 1 ¼" H, 6 ½" L with Handles
(12.7 x 3.2, 16.5 cm)
- CIPR6250** 19 oz. (561.9 mL)
6 ¼" Dia. x 1 ½" H, 8 ¾" L with Handles
(15.9 x 3.8, 22.2 cm)
- CIPR7251** 27 oz. (798.5 mL)
7 ¼" Dia. x 1 ¾" H, 9 ⅝" L with Handles
(18.4 x 4.4, 24.5 cm)
- CIPR42** 9 oz. (266.2 mL)
4" Dia. x 2" H, 5 ⅝" L with Handles, 3" H with Knob
(12.7 x 5.1, 14.3, 6 cm)
- CIPR5500** 19 oz. (561.9 mL)
5" Dia. x 2 ¼" H, 6 ½" L with Handles, 3 ¾" H with Knob
(12.7 x 5.7, 16.5, 9.5 cm)
- CIPR5526** 27 oz. (798.5 mL)
5 ½" Dia. x 2 ⅝" H, 7 ⅝" L with Handles, 4" H with Knob
(14 x 6.6, 19.4, 10.2 cm)

Oval Casseroles and Pots

- CIPOV856** 27 oz. (798.5 mL)
8 ½" L x 6" W x 1 ¾" H, 10 7/8" L with Handles
(21.6 x 15.2 x 4.5, 27.6 cm)
- CIPOV9567** 36 ½ oz. (1.1 L)
9 ½" L x 6 ¾" W x 2" H, 12" L with Handles
(24.1 x 16.2 x 5.1, 30.5 cm)
- CIPOV63** 11 ½ oz. (340.1 mL)
5" L x 2 ⅝" W x 2" H, 6 ½" L with Handles, 3" H with Knob
(12.7 x 6.7 x 5, 16.5, 7.6 cm)
- CIPOV6040** 17 ½ oz. (517.5 mL)
6" L x 4" W x 2 ½" H, 7 ½" L with Handles, 3 7/8" H with Knob
(15.2 x 10.2 x 6.4, 19.1, 9.8 cm)
- CIPOV745** 23 ½ oz. (695 mL)
7" L x 4 ½" W x 2 ¼" H, 8 ½" L with Handles, 4" H with Knob
(17.8 x 11.4 x 5.7, 21.6, 10.2 cm)

Mini Griddle

- CIG85** 8 ¼" L x 5 ¾" W x ¾" H, 9 ½" L with Handles
(21 x 14.6 x 1.9, 24.1 cm)