



3-Compartment Food Container

EC-16- 9" x 9", 3.5" deep 22.9 cm x 22.9 cm, 8.9 cm 1 dz.



Single Entrée Food Container

EC-17- 9" x 9", 3.5" deep 22.9 cm x 22.9 cm, 8.9 cm 1 dz.



Half Size Food Container

EC-18- 9" x 6.5", 2.5" deep 22.9 cm x 16.5 cm, 6.4 cm 1 dz.



3-Compartment Food Container

EC-12-1- 9" x 9", 2.75" deep 23 cm x 23 cm, 7 cm 1 dz.



Single Entrée Food Container

EC-10-1- 9" x 9", 3.5" deep 23 cm x 23 cm, 8.9 cm 1 dz.



3-Compartment Food Container

EC-09-1- 9" x 9", 3.5" deep 23 cm x 23 cm, 8.9 cm 1 dz.



Half Size Food Container

EC-11-1- 9" x 6.5", 2.5" deep 23 cm x 16.5 cm, 6.4 cm 1 dz.



2-Compartment Food Container

EC-15-1- 10" x 8", 3" deep 25.4 cm x 20.3 cm, 7.6 cm 1 dz.



Single Entrée Food Container

EC-08-1- 4.75" x 4.75", 3.25" deep 12.1 cm x 12.1 cm, 8.3 cm 2 dz.