



Chop Plate
HL26130ABWA
13 1/4" x 1 1/4"



Rectangle Platter
HL18110ABWA
14 1/4" x 6 3/4"



Salad/Pasta Bowl
HL20480ABWA
8 1/2" x 3" (54 oz)
HL20470ABWA
7 3/8" x 2 1/2" (30 oz)



Onion Soup Bowl (Body Only)
HL4760BBWA
4 7/8" x 2 5/8" (12 oz)
Cover Only
HL4760CBWA



Side Handle Soup
HL11920ABWA
4 3/4" x 2 1/2" (10 oz)



Side Handle Soup
HL6430ABWA
4 3/4" x 2 1/4" (16 oz)



3 Compartment Dish
HL19010ABWA 9"
Scarlet 3 Compartment Dish
HL31901326 9"



Oval Jelly/Butter Dish
HL9170ABWA
3 1/2" x 3 1/8" x 1 1/4"
(1 1/2 oz)



Deep Oval Baker
HL7060ABWA
6" x 4 1/4" (11 oz)



Round Soufflé/
Crème Brulée
HL8640ABWA
5 1/4" x 1 1/8" (8 oz)
HL8630ABWA
4 1/2" x 1 1/4" (5 oz)



Oval Fluted Soufflé/
Crème Brulée
HL8530ABWA
6" x 4 1/2" (6 1/2 oz)



Oval Rarebit/Au Gratin
HL5280ABWA 9 1/8" x 4 7/8" (12 oz)
HL5210ABWA 9 1/4" x 5" (10 oz)
HL5270ABWA 8 1/4" x 4 1/4" (8 oz)
HL5200ABWA 8" x 4 3/8" (6 oz)



Round Au Gratin/Shirred Egg
HL4340ABWA
6 1/2" x 1 1/8" (12 oz)



Round Au Gratin
HL5130ABWA
6 1/4" (10 oz)



Oval Baker
HL570343ABWA
6" x 4 1/2" (8 oz)
HL5700ABWA
5 1/2" x 4" (6 oz)



Round Casseroles
HL630BBWA
2 1/4" x 4 3/4" (9 oz)



Fluted Ramekin
HL834122ABWA 3 1/4" x 1 3/8" (4 oz)
HL844122ABWA 3 1/8" x 1 3/8" (3 oz)
HL8340ABWA 2 7/8" x 1 3/8" (2 3/4 oz)
HL8440ABWA 2 3/4" x 1 1/8" (2 oz)



Soufflé
HL5000ABWA
4 1/2" x 2 1/8" (12 oz)
HL4980ABWA
4" x 2" (8 oz)



Flared Ramekin
HL8290ABWA
2 1/4" x 1 1/2" (2 oz)
HL8280ABWA
2 3/8" x 1 1/4" (1 oz)



Round Ramekin
HL3620ABWA
2 7/8" x 1 3/8" (2 1/2 oz)



Round Ramekin/
Cheese Pipkin
HL9150ABWA
1 1/4" x 2 3/8" (2 oz)



Mug
HL44780ABWA
4" x 3 1/2" (12 oz)



London Teapot
HL820ABWA
6 3/4" x 4 3/8" x 3 3/4"
(16 oz)



Handled Empire Creamer
HL1950ABWA
2 5/8" (3 1/2 oz)



Unhandled Tankard Creamer
HL377122ABWA
2 1/2" x 2 1/8" x 2 5/8" (3 oz)
HL376122ABWA
2 1/8" x 1 3/4" x 2 1/8" (2 oz)



Sugar Packet Holder
HL7160ABWA
3 3/8" x 2 5/8"