

Fryer Accessories

Part No.	Description	Ship Wt. [lb]
Countertop Single Pot Fryer Accessories		
21506	Basket, half-size (2 per fry pot) (LLF14)	2
22728	Cord set, 30 AMP, 1Ø, NEMA 6-50P (F55)	1
20820	Basket, half-size (2 per fry pot) (F1725)	2
20519	Fry Pot, replacement (F1725)	9
20161	Basket, half-size (2 per fry pot) (LLF14/F49/55/58)	2
20162	Basket, full-size (1 per fry pot) (F49/55/58)	2
20169	Fry pot, 15 lb. capacity (F49/55/58)	7
115714	Fry pot replacement, 15 lb. capacity (F15), 1 required	
21010	Fry pot cover (F49/55/58)	3
HSFB-LH	1/2 size basket (left hanging) - Fits the following models: F15, F30 & GF15	-
HSFB-RH	1/2 size basket (right hanging) - Fits the following models: F15, F30 & GF15	-
FSFB-LH	Full size basket (left hanging) - Fits the following models: F15, F30 & GF30	-
FSFB-RH	Full size basket (right hanging) - Fits the following models: F15, F30 & GF30	-
Built-In Single Pot Fryer Accessories		
20161	Basket, half-size (2 per fry pot)	2
20162	Basket, full-size (1 per fry pot)	2
20169	Fry pot, 15 lb. capacity	7
Countertop Dual Pot Fryer Accessories		
20161	Basket, half-size (2 per fry pot)	2
20162	Basket, full-size (1 per fry pot)	2
20169	Fry pot, 15 lb. capacity	7
20563	Legs, set of four, 4" adjustable (F1725)	5
115714	Fry pot replacement, 15 lb. capacity (F15), 1 required	
21010	Fry pot cover (F49/55/58)	3
HSFB-LH	1/2 size basket (left hanging) - Fits the following models: F15, F30 & GF15	-
HSFB-RH	1/2 size basket (right hanging) - Fits the following models: F15, F30 & GF15	-
FSFB-LH	Full size basket (left hanging) - Fits the following models: F15, F30 & GF30	-
FSFB-RH	Full size basket (right hanging) - Fits the following models: F15, F30 & GF30	-
Built-In Dual Pot Fryer Accessories		
20161	Basket, half-size (2 per fry pot)	2
20162	Basket, full-size (1 per fry pot)	2
20169	Fry pot, 15 lb. capacity	7
Celsius Knobs for Fryers		
Z21370	Celsius knobs in lieu of Fahrenheit knobs (1 each) F15 Fryer (2 each) F30 Fryer (PRICE PER KNOB)	2

