



JW452T - Round Two-Tone Bowl
4 1/4" dia. x 2 5/8" h., 12 oz.



JW4432T - Round Two-Tone Bowl
5 1/4" dia. x 3" h., 24 oz.



JW542T - Round Two-Tone Bowl
6 3/4" dia. x 3 1/2" h., 48 oz.



JW642T - Round Two-Tone Bowl
7 3/4" dia. x 4" h., 64 oz.



JW92T - Round Two-Tone Bowl
9" dia. x 2 1/2" h., 44 oz.



JW552T - Square
Two-Tone Plate
5" sq. x 3/4" h.



JW952T - Rectangular Two-Tone Plate
9" x 5" x 1" h.



JW3252T
Two-Tone Sauce Dish
3 1/4" x 2 1/2" x 1" h., 2 oz.



JW1382T
Rectangular Two-Tone Plate
13" x 8" x 1" h.



JWL11852T
Two-Tone Bento Box Lid
11 1/4" x 8 3/4" x 1" h.

JW11852T
Two-Tone Bento Box
10 3/4" x 8 3/8" x 2" h.



020-3 - Soup Spoon
5 1/2" L.



CH105 - Chop Sticks
10 1/2" L.

Also available in White (W) & Ebony Sand (ES), not available in Red. Available in Black Matte (BM), Black Gloss (BG)

BLACK RED (BR)



KARMA



JW452T - Round Two-Tone Bowl
4 1/4" dia. x 2 5/8" h., 12 oz.



JW4432T - Round Two-Tone Bowl
5 1/4" dia. x 3" h., 24 oz.



JW32T - Round Two-Tone Bowl
6" dia. x 3 1/2" h., 32 oz.



JW542T - Round Two-Tone Bowl
6 3/4" dia. x 3 1/2" h., 48 oz.



JW642T - Round Two-Tone Bowl
7 3/4" dia. x 4" h., 64 oz.



JW92T - Round Two-Tone Bowl
9" dia. x 2 1/2" h., 44 oz.



JW552T - Square
Two-Tone Plate
5" sq. x 3/4" h.



JW952T - Rectangular Two-Tone Plate
9" x 5" x 1" h.



JW3252T
Two-Tone Sauce Dish
3 1/4" x 2 1/2" x 1" h., 2 oz.



JW1382T
Rectangular Two-Tone Plate
13" x 8" x 1" h.



JWL11852T
Two-Tone Bento Box Lid
11 1/4" x 8 3/4" x 1" h.



JW11852T
Two-Tone Bento Box
10 3/4" x 8 3/8" x 2" h.



020-3 - Soup Spoon
5 1/2" L.

Also available in White (W) & Black (B),
not available in Red.



CH105 - Chop Sticks
10 1/2" L.

Available in Black Matte (BM), Black Gloss (BG)

EBONY SAND (ES)