

**KARMA**



**JW452T** - Round Two-Tone Bowl  
4 1/4" dia. x 2 5/8" h., 12 oz.



**JW4432T** - Round Two-Tone Bowl  
5 1/4" dia. x 3" h., 24 oz.



**JW32T** - Round Two-Tone Bowl  
6" dia. x 3 1/2" h., 32 oz.



**JW542T** - Round Two-Tone Bowl  
6 3/4" dia. x 3 1/2" h., 48 oz.



**JW642T** - Round Two-Tone Bowl  
7 3/4" dia. x 4" h., 64 oz.



**JW92T** - Round Two-Tone Bowl  
9" dia. x 2 1/2" h., 44 oz.



**JW552T** - Square  
Two-Tone Plate  
5" sq. x 3/4" h.



**JW952T** - Rectangular Two-Tone Plate  
9" x 5" x 1" h.



**JW3252T**  
Two-Tone Sauce Dish  
3 1/4" x 2 1/2" x 1" h., 2 oz.



**JW1382T**  
Rectangular Two-Tone Plate  
13" x 8" x 1" h.



**JWL11852T**  
Two-Tone Bento Box Lid  
11 1/4" x 8 3/4" x 1" h.



**JW11852T**  
Two-Tone Bento Box  
10 3/4" x 8 3/8" x 2" h.



**020-3** - Soup Spoon  
5 1/2" L.

Also available in White (W) & Black (B),  
not available in Red.



**CH105** - Chop Sticks  
10 1/2" L.

Available in Black Matte (BM), Black Gloss (BG)

**EBONY SAND (ES)**