

Convotherm 4 easyDial – Quick Reference Guide for Fully Automatic Cleaning

⚠️ WARNING **Contact with cleaning agents**
Risk of chemical burns and skin, eye, and respiratory tract irritation

⚠️ WARNING **Hot surfaces**
Risk of burns when there are high temperatures on the inside and at the combi oven vents

⚠️ WARNING **Spraying water inside while the oven is hot**
Risk of scalding posed by hot steam


Open/empty the oven




Check cleaning agents




Check connections




Press the 'Clean' icon



Select a cleaning level



Close the unit door




Start




Check the inside



Close the unit door



Cleaning will start automatically



Cleaning in progress – please wait



Cleaning done




Open the unit door/check results



Clean oven drain



Leave unit door ajar




Legend:

	Clean		
CL 1	Level 1 - light	CL 1d	Level 1 - light, with steam disinfection and drying
CL 2	Level 2 - medium	CL 2d	Level 2 - medium, with steam disinfection and drying
CL 3	Level 3 - heavy	CL 3d	Level 3 - heavy, with steam disinfection and drying
CL 4	Level 4 - very heavy	CL 4d	Level 4 - very heavy, with steam disinfection and drying

- Open unit door
- Close unit door
- Out of rinse aid
- Out of cleaning agent
- Not enough water

Weekly manual cleaning:



- 1) Fan screen
 - Clean by hand with a slightly damp cloth and common household dishwashing liquid
- 2) Hygienic removable gasket
 - Wipe clean by hand using a soft cloth and common household dishwashing liquid
 - Wipe clean with a soft cloth and water
- 3) Door drip tray
 - Clean by hand using a soft cloth and common household dishwashing liquid
 - Wipe clean with a soft cloth and water

These instructions are meant to supplement the operating manual for your unit and should only be used together with it while observing all safety information and instructions.