

WHITTIER ACCESSORIES

				
WTR-56RECDISH Rect. Dish 5.25" x 6", 13 oz cp: 36	WTR-3RECBWL Rect. Bowl 3.7" x 2.8", 3 oz cp: 18	WTR-34RECBWL Rect. Bowl 4" x 2.5", 2.5 oz cp: 144	WTR-34LEAFBWL Leaf Bowl 4" x 3.25", 3 oz cp: 96	WTR-4CANOE BOWL Canoe Tid Bit Bowl 3.75", 1 oz cp: 192
				
WTR-5DPOVLBWL Oval Bowl Tid Bit Tray 4.25" x 2.5", 4 oz cp: 36	SOMB-5BWL Oval Rim Bowl 5.4" x 3.75" x 1.75", 2 oz cp: 48	WTR-5BOATBWL Bowl 5.25", 6 oz cp: 48	WTR-3TPRBWL-LID Tapered Sqr. Lid 3.5" cp: 96	WTR-3TPRBWL Sqr. Tapered Bowl W/Removable Lid 3.5", 6 oz cp: 72
				
WTR-5FTDWVBWL Wavy Footed Bowl 4.5" x 2.5", 5 oz cp: 48	WTR-8RFLBWL Ruffle Round Bowl 7.75", 8 oz cp: 24	WTR-5SLNTBWL Angle Bowl 4.75", 5oz cp: 48	WTR-4SLNTBWL Tall Slant Bowl 4", 4 oz cp: 72	WTR-3SLNTBWL Tall Slant Bowl 3.25", 2 oz cp: 144
				
WTR-18 Covered Sugar 13 oz cp: 6	WTR-16 Creamer 11 oz cp: 6	WTR-14 Sqr. Tea Pot 8", 20 oz cp: 18	WTR-8TEAPOT Teapot W/Handle 8.25", 20 oz cp: 24	WTR-7TEABAG Teabag Holder 4.5" x 3.25 cp: 144
				
WTR-3SUGRBWL Sugar Bowl W/Lid 3.5", 8 oz cp: 48	WTR-5SQBX Sugar Packet Holder 5.125" x 2.875" cp: 48	WTR-34 Covered Butter 8.5" x 4.8" cp: 12	WTR-2SAUDSH Butter Dish 7.85" x 4.1 cp: 24	WTR-2SAUDSH Butter Dish 3.75", 1.5 oz cp: 72