

WHITTIER ACCESSORIES

				
WTR-20GRAVY Gravy Boat 6.5", 20 oz. cp: 16	WTR-25 Gravy Boat 16 oz. cp: 24	WTR-GRVYBOAT Gravy Boat 5.5", 2 oz. cp: 72	WTR-3GRAVY Gravy Tid Bit 4", 2 oz. cp: 144	WTR-SM3PKT Small 3-Pocket Tray 15.5" x 6.125" cp: 18
				
WTR-10CAKESTND Cake Stand W/Foot 10.5" cp: 4	WTR-8CAKESTND Cake Stand W/Foot 8.5" cp: 12	WTR-4CAKESTAND Cake Stand W/Foot 4" cp: 96	WTR-4SQ2BWL Divided Sqr. Bowl 9.75" x 4.25", 8 oz. cp: 24	WTR-16CTRPLRBWL 4-Pocket Caterpillar Bowl 16" x 4, 4.5 oz. cp: 16
				
WTR-SPOON Chinese Wonton Spoon 5.25" cp: 36	WTR-4TAPASPOON Tapas Spoon 4.25", 1 oz. cp: 288	WTR-4TBSPOON Spoon 4" cp: 360	WTR-SMSPOON Small Spoon W/Chopstick Holder 3.625" cp: 36	WTR-CHOPSTICKS Bamboo Chopsticks Set 8.75" cp: 12
				
WTR-SUSHIBT Sushi Boat 12" x 5" cp: 24	WTR-13-11REC Rect. Sushi Plate 12.875" x 9.125" cp: 12	WTR-SAKEBTL Sake Bottle 5 oz. cp: 12	WTR-SAKECUP Sake Cup 1.5 oz. cp: 36	WTR-3DIV Divided Sauce Dish 3" cp: 24
				
WTR-5FTDSQ Sqr. Dish 5.25" cp: 48	WTR-EGGCUP Egg Cup 2" cp: 96	WTR-8TRI Triangle Plate 9.875" cp: 12	WTR-SQAPTZR Appetizer Plate W/ Wine Cup Holder 9" cp: 24	WTR-OLIVE Olive Server 16" cp: 24