



41. 8oz Spiral® Stackable
Cup, White
3 dia x 2.5, 8oz
Pack 12
DCS025WHP23



42. 5.75" Spiral®
Saucer, White
5.75 dia x .75
Pack 12
DCS024WHP23



43. 8oz Spiral®
Cup, White
3.5 dia x 2.75, 8oz
Pack 12
DCS023WHP23



44. 5.75" Spiral®
Saucer, White
5.75 dia x .75
Pack 12
DCS024WHP23



45. 3oz Spiral®
Cup, White
2.5 dia x 2.25, 3oz
Pack 12
DCS021WHP23

46. 4.75" Spiral®
Saucer, White
4.75 dia x .75
Pack 12
DCS022WHP23



47. 15oz Spiral® Teapot, White
4 dia x 4, 15oz
Pack 6
BTP002WHP12

Replacement Spiral®
Teapot Lid, White
Pack 6
BTP101WHP12



48. Spiral® Packet Holder, White
4.5 x 3 x 2.25
Pack 12
TSP008WHP23



49. 6oz Spiral® Creamer, White
3.25 dia x 2.5, 6oz
Pack 12
TCR006WHP23



50. 6oz Spiral® Sugar Pot , White
3.25 dia x 2.75, 6oz
Pack 12
TSC004WHP23



51. Double Wide Spiral®
Ramekin, White
5.75 x 2 x .75, 3oz
Pack 12
DSD047WHP23



Shown with:
1oz Square Canvas®
Ramekin, White
DSD034WHP24
Page 23



52. 3.25" Spiral® Dish
3.25 dia x 1, 3oz
Pack 12
DSD008WHP23
DSD008BEP23

white
eurowhite®



53. 2.75" Square Spiral® Dish
2.75 x 2.75 x 1.25, 3oz
Pack 12
TSH007WHP23
TSH007BEP23

white
eurowhite®