

LA RADIOSA

INSTALLATION CHECKLIST

GAGGIA
MILANO

GENERAL MACHINE ENVIRONMENT

- ☐ The installation area is clean and clear of dust and tools. It is not located in an active construction zone.
- ☐ The counter accommodates the machine size and weight:
 - Dimensions: 14.5" (W) x 31" (H) x 23.1" (D)
 - Dimensions with NSF/ANSI 4 legs: 14.5 (W) x 33.6 (H) x 23.1 in (D)
 - Weight: 97 lb
- ☐ An access hole has been pre-drilled in the counter for drainage and power in accordance with model installation template
- ☐ Hole in counter is fitted with a collar to protect electrical cord, water line & drain tube.
- ☐ Machine can safely be installed with a minimum clearance of 1 5/8 inch from the back wall.

ELECTRICAL REQUIREMENTS

La Radiosa Specifications

208-240 V / 60 HZ, 5800W
NEMA L6-30P

- ☐ Power outlet receptacle is NEMA L6-30P.
- ☐ Dedicated electrical circuit meets the La Radiosa power requirements.
- ☐ No extension cord or power strip on the circuit.



WATER SPECIFICATIONS

Pressure & Hardness

- ☐ Pressure is between 21.7 PSI and 123.28 PSI.
- ☐ pH range is between 6.5 and 7.5.
- ☐ Hardness (TDS) is between 89 PPM and 142 PPM.
- ☐ Machine water line is equipped with softness/filtration system and descaling device.

Water Network

- ☐ The water network provides cold, drinkable tap water.
- ☐ Dedicated 3/8" diameter water line.
- ☐ Shutoff valve with a 3/8" compression fitting on machine's end.

HIGHLY RECOMMENDED: Connection to a floor drain in accordance with local health code.